

Heininger Auditorium

Larrance Academic Center



Heininger Auditorium, located in the Larrance Academic Center, has a ceiling mounted data and video projector, and enhanced sound system. The equipment is located in a lectern near the foot of the stage.

Additional microphones or audiovisual equipment may be requested for use in this room.



To begin, turn on the red main power switch located at the top right of the equipment rack.

To display the computer on the projector, turn on the computer and log in with your North Central College credentials. The computer is located in the equipment rack at the front of the room.

Use the Extron push button controller to turn on the projector. This controller is located on the top left of the lectern, next to the monitor.





Press “ON” to turn on the projector.

The projector automatically turns on to the correct input, there is never a NEED to select an input.

The projector will turn on, and display on the back wall of the stage after warming up for about 20 seconds.

Audio from the computer can be played in the room. Make certain the computer’s playback device is set to “Speakers (Realtek High Definition Audio)”



If another playback device is displayed, click on the speaker icon to select the correct device. Then click the arrow next to the name of the device and choose “Speakers (Realtek High Definition Audio)”.

Adjust the volume of the computer on the taskbar. For more control over the audio system in the room, use the mixing board located in the equipment rack.



Turn the “COMP” knob to increase or decrease the volume of the computer audio going into the audio system. Make sure the “MASTER” knob is turned up as well. The “MASTER” knob adjusts all of the inputs equally, while the “COMP” knob only adjusts the computer volume.

A 3.5mm stereo mini cable is provided for connecting an audio device, such as a phone, for playing music over the audio system. Use the “IPAD” knob to adjust the volume.

An HDMI cable is provided for connecting a laptop computer to the projector and audio system. Simply turn on the projector, then connect your laptop to the HDMI cable. The laptop will automatically switch from the desktop computer to display on the projector. Disconnecting the laptop will automatically switch back to displaying the desktop computer.



When finished using the equipment, please remember to turn off the projector by pressing the “OFF” button on the Extron controller.